



FILM CUTTER 120, Art nos. 8664, 8665, 8666, 8667

The film cutter 120 is a precision device for cutting roll film 120/220, 70 mm film and for cutting down large format film.

The slide is cut precisely and in right angles by the double guillotine of tempered steel. Four pins enables the correct positioning of the film.

Place the device on a light panel, with the pressure plate and the guillotine opened. Put the film on the transparent base plate and adjust it for the correct cutting.

Hold the film slightly against the positioning pins and close the pressure plate and press the double guillotine downwards and cut the film.

If the model 4x4 is used for cutting to 4x4, turn the film and repeat the cutting in proper position.

The front positioning pins can be removed if desired, for example when cutting large formats.